

Deep-Learning-Assisted Schlieren Analysis of Cellular Flame Morphology in Wall-Ignited NH₃/H₂ Combustion

MariNH₃

Clean, green ammonia engines for maritime

Tuna Murat Bodur, Prof. Antonino La Rocca, Prof. Alasdair Cairns
The University of Nottingham, Powertrain Research Group
tuna.bodur@nottingham.ac.uk



Abstract

This work presents a fine-tuned Cellpose-SAM workflow for cellularity detection in wall-ignited 40%H₂/60%NH₃ Schlieren flame images at ambient conditions. Default CPSAM predictions were manually corrected to generate ground-truth masks, which were then used to adapt the model to the present CVCC imaging system. Validation on independent repeat-experiment images showed improved segmentation reliability and cell-count agreement compared with default model, enabling quantitative extraction of cell boundaries, centroids, projected areas and cell counts.

Introduction

1. NH₃/H₂ blends are promising candidates for low-carbon marine combustion, but ammonia's low reactivity and slow flame speed make stable flame propagation challenging. Hydrogen enrichment improves combustion reactivity, yet it can also promote flame-front wrinkling, intrinsic instabilities and cellular flame formation.
2. Cellular flame structures are difficult to quantify from Schlieren images, especially for non-spherical flames generated by wall-mounted ignition.

Research need

A robust and repeatable image-processing workflow is required to quantify cellular flame morphology in wall-ignited NH₃/H₂ flames, where conventional spherical-flame assumptions are not directly applicable.

Experimental Test Setup and Control






Fig 1. CVCC based Z-type Schlieren imaging setup and deep-learning-assisted image-processing workflow.

Image Processing, Cellularity Detection, and Results

Representative CVCC Schlieren images, manual masks, model fine-tuning, and improved segmentation



- Default CPSAM was used to obtain initial cellular-structure predictions.
- Manual correction generated ground-truth masks for flame-cell boundaries and centroids.
- Corrected masks were used to fine-tune Cellpose-SAM for wall-ignited Schlieren images.
- Extracted outputs include cell boundaries, centroids, projected cell area and cell count.





Fig. 2. Segmentation validation of default CPSAM and fine-tuned Cellpose-SAM



- 1) IoU measures the overlap between predicted and manual masks.
 - 2) A match is accepted when IoU ≥ 0.50 (or 0.75).
 - 3) Precision quantifies extra detections.
 - 4) Recall quantifies missed cells.
 - 5) F1-score balances precision and recall.
- $$IoU = \frac{|P \cap G|}{|P \cup G|}$$
- $$Precision = \frac{TP}{TP + FP}$$
- $$Recall = \frac{TP}{TP + FN}$$
- $$F1 = \frac{2PR}{P + R}$$
- P = Predicted Mask, G = Manual Mask, FP = False Positive, TP = True Positive, FN = False Negative

- The fine-tuned model clearly outperformed default CPSAM in segmenting cellular flame structures
- AP@0.50 improved from 0.45 to 0.98, while F1@0.50 improved from 0.70 to 0.99.
- Mean absolute cell-count error decreased from 3.42 to 0.33 cells/image, showing much closer agreement with manual GT.


Conclusion

- Cellpose-SAM was successfully fine-tuned for the present wall-ignited CVCC Schlieren imaging system.
- The fine-tuned model improved cellularity detection, increasing AP@0.50 from 0.45 to 0.98 and F1@0.50 from 0.70 to 0.99.
- The workflow provides a repeatable basis for extracting cellularity metrics from 40%H₂/60%NH₃ flame images.




Ongoing Studies

- Extend the validated model workflow to the full 1, 3 and 5 bar tests for 40%H₂/60%NH₃.
- Support future journal-scale analysis of NH₃/H₂ flame cellularity and instability.



Acknowledgments



The PhD candidate, Tuna Murat Bodur is supported by the Republic of Turkey Ministry of National Education, General Directorate of Higher and Foreign Education, and the Turkish Government Study Abroad Program.

The partnership



Funded by

